





Kontingenztafel: abhängigen Typs Intermezzo (Total: 30 opp.)		
Wohnfläche des Gebäudes	Bauwerknummer	
A1	2	1, 2
A1'	1	3
A2	8	5, 7, 12, 14, 19, 21, 26, 28
A2'	8	6, 8, 13, 15, 20, 22, 27, 29
A2'39	4	4, 11, 18, 25
A3	4	9, 16, 23, 30
A4	3	10, 17, 24
Total	30	

